

2) Mapa pre reguláciu plniaceho tlaku (úpravca s novou ponukou)

Hodnoty navýšenia plniaceho tlaku dosahujú cez 340 mbar!!! Výsledný plniaci tlak tak prevyšuje hodnotu 2520mbar, čo pri vozidle, ktoré ma cez 10 rokov určite turbo nevydrží.

troke rpm	- (Mnozstvo paliva,otáčky motora) /-									
	0,0	5,0	10,0	15,0	20,0	25,0	30,0	35,0	40,0	55,0
0	0	0	0	0	0	0	0	0	0	0
21	0	0	0	0	0	0	0	0	0	0
1008	0	0	0	0	0	0	0	0	0	0
1260	0	0	0	0	0	0	0	0	6	0
1491	0	0	0	0	133	152	247	228	171	171
1743	0	0	0	0	133	188	247	313	183	133
1911	0	0	0	0	133	190	275	329	203	152
2058	0	0	0	0	133	168	257	323	221	220
2247	0	0	0	0	133	178	275	307	199	258
2499	0	0	0	0	133	198	256	270	199	300
3003	0	0	0	0	133	208	218	228	234	345
3507	0	0	0	0	133	209	190	172	205	326
3990	0	0	0	0	133	161	190	107	147	235
4242	0	0	0	0	66	85	76	81	111	208
4494	0	0	0	0	0	0	0	12	30	95
4746	0	0	0	0	0	0	0	0	0	0

troke rpm	- (Mnozstvo paliva,otáčky motora) /-									
	0,0	5,0	10,0	15,0	20,0	25,0	30,0	35,0	40,0	55,0
0	198	198	198	198	198	198	198	198	198	198
21	1002	1012	1072	1141	1190	1294	1330	1350	1410	1470
1008	1002	1020	1090	1150	1200	1298	1339	1352	1418	1519
1260	1002	1040	1120	1200	1250	1377	1474	1580	1650	1700
1491	1002	1060	1140	1220	1433	1602	1797	1928	2081	2211
1743	1002	1065	1160	1270	1483	1718	1897	2113	2272	2383
1911	1002	1070	1165	1330	1533	1758	1965	2171	2350	2452
2058	1002	1075	1170	1360	1553	1768	1975	2191	2380	2520
2247	1012	1090	1200	1390	1583	1788	2005	2191	2374	2520
2499	1021	1110	1230	1410	1593	1808	2006	2174	2374	2520
3003	1050	1150	1260	1430	1613	1818	1988	2178	2371	2520
3507	1070	1220	1350	1450	1623	1819	1965	2140	2324	2475
3990	1090	1250	1380	1450	1628	1771	1965	2092	2248	2372
4242	1100	1250	1370	1450	1549	1684	1856	2047	2143	2276
4494	1149	1250	1358	1444	1482	1600	1778	1922	2000	2095
4746	1198	1256	1356	1444	1492	1600	1770	1800	1850	1850

